I. Care Instructions

1. Before using the PopUp please inspect the harness, seat, and cover for any issues and to ensure they are properly installed.
2. Seat Cover Care: Wipe down seat cover with water and sponge to remove stains and air dry. Do not put cover in washing machine.
3. Frame Care: Wipe down frame with water and do not use any cleaners with solvents.

II. Part List



① Cover
② Back
③ Rear Legs
④ Leg Connection
● Foot Bumpers
⑥ Feeding Tray
⑦ Leg Guard
⑧ 3 Point Harness
⑨ Footrest

III. Installation & Use

(1) Unpackaging & Folding

① Remove from packaging.



Pic1-1

② To unfold the PopUp pull the handle on the bottom of the seat up and expand the High Chair as shown below.



Pic1-2

③ To fold the PopUp, pull the handle on the bottom of the seat out and fold the chair forward.



Pic1-3

(2) Feeding Tray

① Slide tray into the two grooves on each arm of the seat to secure the feeding tray.



Pic2-1

② Push tray toward the back of the seat until you hear the tray lock into place.



Pic2-2

③ Press button under tray and pull away from seat to remove from frame.



Pic2-3

(3) Seat Cover

① Drape flaps of seat cover over each chair arm and connect them to the underside of the cover.



Pic3-1

② Connect seat cover to frame by snapping buttons on cover near the feeding tray.



Pic3-2

(4) Safety Harness Instructions

① Push left and right safety harness straps into the center buckle until you hear them "click" indicating that they are secured. Press button on center buckle to unlock.



Pic 4-1



Pic4-2

Warning: Always use safety harness when High Chair is in use.

IV. Specifications

Model: PRI-440
Quantity: 1 High Chair
Standard: ASTM F404-18a
Materials: Steel, Polypropylene, Polyurethane

Recommended Ages: 6-36 Months
Max Weight: 35lbs/16kg

It is recommended that the high chair be used only by children capable of sitting upright unassiste.

Base Dimensions: 23in Wide x 30in Deep/58cm x 76cm Floor to Top Of Chair: 37.5in/95cm
Floor to Bottom of Seat: 22.5in/57cm
Floor to Tray: 30in/76cm



Folded

LIMITED WARRANTY POLICY

PRIMO® warrants that the PRIMO® PopUp Folding High Chair is accompanied with a limited warranty and is free from defects resulting from material, missing parts or workmanship for a period of 90 days from the date of original purchase. This warranty only applies to the original purchaser of the product. This LIMITED WARRANTY does not apply to defects from normal wear and tear, product misuse, product abuse, after market alterations or failure to follow instructions supplied for assembly, use, maintenance and care of the product.

If any defect is discovered during the 90 day warranty period, please call (973) 926-5900 or e-mail info@primobaby.com with a description of the problem and a request for return authorization of parts or replacement. If PRIMO® determines that a defect is covered by this limited warranty, PRIMO® will, at its option, either repair, send new parts or replace product. The Limited Warranty extends to repaired and replacement products and components only through the end of the original 90 day limited warranty period from the original date of purchase. When authorization is issued for replacement or parts, send (postage prepaid) to:

PRIMO
149 Shaw Avenue
Irvington, NJ 07111 USA

The warranty details above shall be in lieu of any and all other warranties.
ALL OTHER WARRANTIES, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY EXPRESSLY DISCLAIMED.

This warranty is valid only with an original dated receipt.

Your remedies under this warranty are limited to repair or replacement of the product or components of the product as determined by PRIMO®. In no event will PRIMO® or any of its retailers, dealers, distributors or resellers be liable for incidental, indirect or consequential damages relating to the product (including any repaired or replacement products or replacement components) or its use.

To activate this limited warranty, the purchaser must complete the enclosed product registration card and have returned it to the PRIMO® address on the enclosed warranty registration card within ninety (90) days of the original purchase date.

⚠ WARNING

FALL HAZARD: Children have suffered severe head injuries including skull fractures when falling from high chairs. Falls can happen suddenly if child is not restrained properly.
1) Always use restraints, and adjust to fit snugly.
2) Tray is not designed to hold child in chair.
3) Stay near and watch child during use.

DANGER DE CHUTE: Les enfants ont souffert de graves blessures à la tête, y compris des fractures du crâne en tombant des chaises hautes.
1) Utilisez toujours des dispositifs de retenue et ajustez-les pour bien les ajuster.
2) Le plateau n'est pas conçu pour tenir l'enfant dans une chaise.
3) Les chutes peuvent survenir soudainement si l'enfant n'est pas retenu correctement.

PELIGRO DE CAÍDA: Los niños han sufrido lesiones severas en la cabeza,
incluyendo fracturas de cráneo que caen de las sillas altas. Las caídas pueden ocurrir repentinamente si el niño no está sujeto adecuadamente.
1) Siempre use restricciones y ajústelas para que se ajusten bien.
2) La bandeja no está diseñada para sostener al niño en la silla.
3) Permanezca cerca y mire al niño durante el uso.

primo®

PopUp Folding High Chair

Ages: 6-36 Months Max: 35lbs/16kg
Made in China

149 Shaw Avenue Irvington, NJ 07111 USA
www.primobaby.com Tel: (973) 926-5900

primo®

PopUp Folding High Chair

Model#: PRI-440
Ages 6-36 Months Max Weight: 35lbs/16kg
PRIMO
149 Shaw Ave, Irvington, NJ, 07111
(973) 926-5900
www.Primobaby.com